

diameter of your pulleys We use a belt length of 60-61" with this mount on installations in our shop. However; this can vary with the

*NOTE: Exhaust Spacers with Headers use the $2\frac{1}{4}$ " long x 5/8" O.D. spacers. With RAMS HORN MANIFOLDS use the $\frac{1}{4}$ " long x $\frac{3}{4}$ " O.D. Spacers at front hole of bracket. With the later DROP-TYPE MANIFOLDS use the 1.1/16" BEFORE tightening the bolts long $\,\%''$ O.D. spacers at both bracket holes. As with any mount system, assemble all of the brackets to engine

It may be necessary to shorten the front exhaust spacer to work with the Factory Power Steering

plating. Parts that have been painted, plated, or modified may not be returned. As with any part of this nature, make sure it fits your application before painting or