



Extra Clearance
ALTERNATOR MOUNT
203L

Small Block Chevy - Long Water Pump
 Driver Side

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

NOTE:

Install bolt into the water pump first. Then determine the number of spacer washers needed between the bracket and the intake manifold. This will vary with the thickness of the various brands of manifolds. **START ALL BOLTS BEFORE TIGHTENING.**

(We use a belt length of 52 to 53" with this mount on installations in our shop. However; this can vary with the diameter of your pulleys.)

The alternator belt will run in the second grooves from the front of the crank and water pump pulleys originally used for the factory compressor. It was designed to be used with our 103R Passenger Side Compressor Mount.

As with any part of this nature, make sure it fits your application before painting or plating. Parts that have been painted, plated, or modified may not be returned.