

1201 Forum Way South - Fort Worth, TX 76140 (817) 531-2665 - FAX (817) 531-3257

This bracket was designed to be used 3/8" Nylock Nut 3/8" x 11/2 1 15/16" Spacer 3/8° × 1″ 2 3/16" Spacer

7/16" × 3 1/4"

3/8" Nylock Nut

3/8" Flat Washer

3/8" x 1 1/

3/8" x 1 1/4"

3/8" Nylock Nut

7/16 x3 1/4"

water pump pulleys. The current G.M. part with Chevrolet double groove crank and 3995642 for the water pump. Numbers are 3744043 for the crank and

When installing the mount, start all bolts and mount the compressor before tightening.

> with the diameter of your pulleys.) our shop. However; this can vary with this mount on installations in (We use a belt length of  $61\ 1/2$ -62"

## 40-126R

COMPRESSOR MOUNT

**PASSENGER SIDE - LOW PROFILE** 348-409 CHEVY

3/8" Nylock Nut

Parts that have been painted, plated, or modified may not be returned. As with any part of this nature, make sure it fits your application before painting or plating.